



# Shark Flex DuoClean Dust Cup Replacement

How to replace the Dust Cup on the Shark Flex DuoClean HV391.

Written By: Christian Fuller



## **INTRODUCTION**

Replace if the container is cracked. Remove and empty to restore suction.

## Step 1 — Dust Cup



- Squeeze Dust Cup release buttons on either side of the component.
- Pull up to release Dust Cup.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-12-11 10:27:43 PM.