




Pioneer FH-X730BS Fuse Replacement

How to replace the fuse on the back of the Pioneer FH-X730BS.

Written By: Cody Pesta



INTRODUCTION

A blown fuse can cause the Pioneer FH-X730BS to be unusable. This guide will show you how to replace the appropriate fuse.



TOOLS:




- [Basic Pliers](#) (1)



PARTS:

- [10 amp fuse](#) (1)
-

Step 1 — Fuse



- Remove the fuse on the back of the Pioneer FH-X730BS. This may require some force. Pliers can be used if needed.
- Replace old fuse with a new one of identical amperage.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-12-11 10:14:51 PM.