



DOSS SoundBox Grille Removal

Here you will learn how to remove the protective speaker grille on your DOSS SoundBox.

Written By: Jimmy Baertlein




 **TOOLS:**

- [iFixit Opening Tools](#) (1)
-

Step 1 — Grille Removal



- Use a small plastic opening tool to gently lift the side of the grille.
- Gently slide the tool to the front of the speaker.
- Repeat the process on the bottom of the grille.
- Gently pull the grille off of the speaker enclosure.

 Pry with caution, for the grille is fragile.

To reassemble your device, follow these instructions in reverse order.