



Power Macintosh G3 Blue and White RAM Replacement

Want to replace or upgrade the RAM on your Power Mac? This is the guide for you!

Written By: Aaron Cooke



INTRODUCTION

My RAM configuration may differ from yours, but the process is exactly the same.



PARTS:


- [1GB \(512 x2\) PC-133 RAM Upgrade Kit \(1\)](#)
-

Step 1 — RAM




- i Unfortunately, I am unable to provide OG content for this step due to my PowerMac's outer case being severely damaged. Once I get my new outer case I will update this step.
- Lift the latch on the right side panel to reveal the internals of the Power Mac.
- i If you are doing this on a hard surface I highly suggest you put a mat down between the door and the ground to prevent scratches.

Step 2



- Push the white tabs next to where your RAM is located away from the RAM chip itself.
- i The RAM chips should move up a tad and become somewhat loose.
- i Your RAM configuration may vary. This process is done the exact same way no matter what your RAM placement looks like.

Step 3



- Pull the RAM chips out of the RAM slots.
- ⓘ That's all folks! That wasn't too hard, was it?
- Second image: RAM remains

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-07 01:29:42 PM.