




ASUS X42J Keyboard Replacement

This guide will articulate the process for replacing the keyboard.


Written By: Robert Martinez



 **TOOLS:**

- [Metal Spudger](#) (1)
 - [Nylon Tipped Tweezers](#) (1)
-

Step 1 — Keyboard



- ⓘ Make sure your device is unplugged and turned off before proceeding.
- Using a [Spudger](#), gently pry up the keyboard.

Step 2



- Rotate the keyboard to face downward.
- Pull out the blue wiring connection. Use [tweezers](#) to make it easier to remove.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-21 08:44:22 PM.