




Dell Inspiron 15-7548 Speaker Replacement

This guide will show you how to replace the speakers on the Dell Inspiron 15-7548.

Written By: brianna cordoway





INTRODUCTION

Is the sound coming out of your laptop distorted or unclear? Consider using this guide to replace the speakers in your device.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Back Panel





- Unscrew the six 2.5x6mm screws and remove them using a Phillips #1 screwdriver.
- Loosen the four 2x3mm captive screws at the bottom.
- ⓘ The four screws on the bottom are captive screws and cannot be removed.

Step 2





- Using the flat head side of the spudger separate the the back panel from the rest of the laptop.
- ⚠ When separating the bottom and right side of the case do not insert the spudger more than half an inch.

Step 3 — Battery




- Disconnect the battery from the motherboard by pulling the black tab attached to the cable.

Step 4




- Remove the four 2.5x6mm screws using a Phillips #1 screwdriver.

Step 5 — Speaker




- Remove the ribbon cable by pulling it out.

Step 6



- Remove the compression caps by using the spudger.

Step 7



- Untangle the wire from the plastic clips and remove the speakers from the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-08 01:27:32 AM.