



Acer Aspire E1-470P-6659 Battery Replacement

How to replace the battery in an Acer Aspire E1-470P-6659

Written By: Faith Lobaton



INTRODUCTION

If you have battery problems or need to remove your battery before replacing other parts of the laptop, use this guide to remove and replace your battery.

TOOLS:

- [Spudger](#) (1)
-

Step 1 — Battery




- Turn off the laptop and disconnect all device cords.

Step 2




- Flip the laptop over so the bottom is facing you.

Step 3



- Insert the tip of the Plastic #3 Spudger into the battery release switch.

Step 4



- Press down and slide to the right and hold in that position.

Step 5



- Take your other hand to slide the battery away from the laptop to remove.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-09-15 11:11:00 AM.