



MSI PR600 MS-16372 Battery Replacement

This guide will demonstrate how to replace a dead battery in a MSI PR600 MS-16372 when laptop will not charge.

Written By: Lauren Mewes



INTRODUCTION

After confirming that your power cord is not faulty, your next step would be to buy a new battery and replace old one. To complete this task you will not need any tools.

Step 1 — Battery




- First, turn off the computer and unplug the power cord.
- ⚠ If laptop is not unplugged from the power cord, you could be at risk of electric shock.

Step 2



- Flip laptop over so that you are looking at the bottom of the laptop.
- Put your left pointer finger on the switch labeled "Battery lock" and your right pointer finger on the switch labeled "Release".

Step 3



- Switch the tab labeled "Battery lock" to the unlocked position.
- Slide the tab labeled "Release" to the right and hold it down.
- While holding the "Release" tab to the right, slide the battery out with your left hand.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-08 01:29:36 AM.