



# HP Beats Special Edition 15-p390nr Battery Replacement

This guide will accomplish the replacement of your HP battery.

Written By: Deziree Mascarenas



## INTRODUCTION

If you find yourself needing to replace your HP Beats Special Edition 15-p390nr battery use this guide to help walk you through the process successfully.

---



### PARTS:

- [HPVI04 Notebook Battery](#) (1)
-

## Step 1 — Battery



- ⚠ Turn computer off before starting.
- Turn the computer over and slide the battery latch to the left to help partially release the battery.
- ⓘ The battery latch is symbolized with a battery icon.

## Step 2



- Lift the frontal part of the battery to remove from your hp.

### Step 3



- Align new battery in battery slot.

### Step 4



- Once new battery is placed into the slot, press down on battery until you hear a “click”.
- ⓘ Clicking noises are normal

To reassemble your device, follow these instructions in reverse order.