




# Keurig B70 Platinum K-Cup Portion Pack Holder Replacement

Replace the portion pack holder on your Keurig B70 Platinum if you encounter any problems with it.

Written By: Thu Hoang



## INTRODUCTION

K-Cup pack holder is stuck?

This guide will show you how to remove and replace the K-Cup Portion Pack Holder for the Keurig B70 Platinum if you're experiencing any problems with the pack holder. Before continuing with the guide, you're going to need a Phillips #2 screwdriver.

---

### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — K-Cup Portion Pack Holder



- Turn off and unplug the Keurig before starting.
- Open the lid and remove the two 11.0 mm screws located below the K-Cup holder.

## Step 2




- Pull the black plastic guard of the K-Cup housing away from the Keurig.
- ⓘ Depending on the angle, the guard can actually fall out instead. Be ready to catch it!

### Step 3





- Push the black button at the bottom of the lid to remove the K-cup holder assembly.
- From the top, lift the assembly out of the Keurig.

### Step 4



- Grab the top and the bottom of the holder assembly and pull it apart.

 Be careful when pulling the assembly. There is a sharp needle!

 This step requires a little force.

To reassemble your device, follow these instructions in reverse order.

