




Lenovo Thinkpad Tablet 1838 Camera Replacement

In this guide we will replace the camera and ribbon cable.

Written By: Juan Rojo



TOOLS:

- [Essential Electronics Toolkit \(1\)](#)
-

Step 1 — Camera



- Start by removing the button covers by prying them off.

Step 2





- Next Remove the two screw found under the buttons.

Step 3



- Using a plastic opening tool carefully pry open the the outer perimeter of the tablet.

Step 4



- Next remove the ribbon cable lift up the tab on the back end and slide it out.
- ⓘ Only the back side of the cable has been removed—the other can remain connected.

Step 5



- Remove this screw and lift out the whole assembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-24 05:01:10 AM.