



Asus A53U-ES21 Hard Drive Replacement

In this guide, we will replace the hard drive in your Asus A53U-ES21.

Written By: Chase Poirier



INTRODUCTION


A malfunctioning hard drive can be the underlying cause of many issues with your laptop. This guide will explain how to replace your hard drive.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



 Make sure the laptop is off.

- Flip the laptop upside down so that the battery is facing you.

Step 2



- Move the two sliders towards the outer edge of the laptop.
- Pull the battery out with your left hand while holding the right slider.

Step 3 — Hard Drive



- Remove the 5mm screw using a Phillips #1 screwdriver.
- Use the iFixit opening tools to remove the hard drive panel.

Step 4



- Pull upwards on the black ribbon on the end of the hard drive.
- Pull the hard drive out from its socket and remove it from the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-18 03:53:42 AM.