



Sony Alpha a7s II Eyepiece Cup Replacement

This guide illustrates how to replace the eyepiece cup portion of the Sony Alpha a7s II camera.

Written By: Jennifer Stott



INTRODUCTION

The eyepiece cup is allowing stray light to come into the viewfinder or has become worn and uncomfortable for the operator to use.

Step 1 — Eyepiece Cup



- Orient your camera so that you are looking at the posterior portion.
- Place each of your thumbs on the interior portions of the eyepiece cup.

Step 2



- Using equal pressure, firmly push the eyepiece cup upwards and away from the viewfinder.
- ⚠ Be careful not to come into contact with the viewfinder lens as the lens can be easily scratched.

To reassemble your device, follow these instructions in reverse order.

