



Dell Inspiron 17R-N7010 Battery Replacement


This guide will show how to detach and replace the battery.

Written By: Brandon Lopez





Step 1 — Battery



-  Be sure to **power off** the laptop and **remove the battery** before proceeding with the disassembly.
- Flip the laptop over and locate the battery compartment on the bottom .

Step 2



- Slide both locks away from the center of the battery.
- The battery can then be removed after hearing a click.
-  To reinstall the battery, slide the battery back in place until you hear a click.

To reassemble your device, follow these instructions in reverse order.