




Propel Star Wars T-65 X-Wing Drone Battery Replacement

If your drone is not lighting up, a possible cause could be a dead drone battery. Follow these steps to learn how to change the battery. No tools needed.


Written By: Alma Robledo



INTRODUCTION

A nonfunctioning drone battery may be the cause of your drone not working. Replacing it is simple, you just need a replacement and no tools are required.

Step 1 — Drone Battery



- Remove the old battery from the drone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-15 04:37:14 AM.