



Lenovo Ideapad 320-15ABR Back Panel Replacement

This guide explains how to remove and replace the back panel for the device in a step-by-step manner.

Written By: Anurag Deb



INTRODUCTION


This guide will show you how to disassemble the back panel for the device.

This guide is also a prerequisite guide for other hardware part replacement.

TOOLS:

- [Magnetic Project Mat](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-


Step 1 — Back Panel



⚠ Before you proceed, make sure your computer is turned off and is not connected to any power source.

- Orient the laptop in such a way that the bottom is facing up and the optical drive is facing to the left of yourself.

Step 2



- Remove the 7mm Phillips #1 screw.


i Be sure to store the screws carefully as they are easy to lose. A magnetic project mat is recommended

Step 3




- Carefully remove the optical drive bracket by pulling the bezel away from the laptop.

Step 4



- Using the Phillips #1 screwdriver, remove the twelve screws around the back panel from the laptop.

Step 5



- Use an opening tool to pry out the back cover.

Step 6



- Remove the back panel by pulling it up and away from the laptop.

To reassemble your device, follow these instructions in reverse order.