



# Lenovo Ideapad 320-15ABR Back Panel Replacement

This guide explains how to remove and replace the back panel for the device in a step-by-step manner.

Written By: Anurag Deb



## INTRODUCTION

This guide will show you how to disassemble the back panel for the device.


This guide is also a prerequisite guide for other hardware part replacement.

---

### TOOLS:

- [Magnetic Project Mat](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-


## Step 1 — Back Panel



**⚠** Before you proceed, make sure your computer is turned off and is not connected to any power source.

- Orient the laptop in such a way that the bottom is facing up and the optical drive is facing to the left of yourself.

## Step 2



- Remove the 7mm Phillips #1 screw.

**i** Be sure to store the screws carefully as they are easy to lose. A magnetic project mat is recommended




### Step 3




- Carefully remove the optical drive bracket by pulling the bezel away from the laptop.

### Step 4



- Using the Phillips #1 screwdriver, remove the twelve screws around the back panel from the laptop.

## Step 5



- Use an opening tool to pry out the back cover.

## Step 6



- Remove the back panel by pulling it up and away from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-15 07:19:20 AM.