



Sony α6500 Battery Replacement

This guide will assist users in removing and replacing the batter of the Sony α6500 camera.

Written By: Olivia Kavanagh



INTRODUCTION

In the case that the battery becomes problematic and needs to be replaced, this guide will provide step-by-step instructions of how to remove and replace it.

Step 1 — Battery



- Make sure the camera is turned off by turning the switch to OFF.

Step 2



- Flip the camera upside down and locate the battery compartment.
- Slide the compartment lock to OPEN to unlock it.

Step 3



- Once the compartment is open, locate the blue lever that keeps the battery in place.
- Push the blue lever aside to release the battery.

Step 4



- Once the battery is released, you can remove the battery from its compartment.

To reassemble your device, follow these instructions in reverse order.