



iPod Touch 5th Generation Front Camera Replacement

prerequisite only

Written By: Andrew Optimus Goldheart




INTRODUCTION

prerequisite only

TOOLS:

- [Spudger](#) (1)
-

Step 1 — Front Camera



- Use the flat end of a spudger to flip the front-facing camera out of its socket in the display assembly.
 - ⚠ There is a small amount of adhesive securing the camera module to its socket, but this should not take very much force. Use the spudger to get in between the black plastic of the camera module and the black plastic of the camera socket and separate them.

To reassemble your device, follow these instructions in reverse order.