



Ring Spotlight Cam Battery Replacement

This guide will help you replace the batteries.

Written By: Smoo Rena



Step 1 — Battery



- Turn Ring Spotlight Cam to the back side and flip upside down

Step 2



- Press down on the top button and open upward

Step 3



- Open Spotlight Cam to remove batteries.

To reassemble your device, follow these instructions in reverse order.