



Dell XPS M1330 Battery Replacement

How to replace a Dell XPS M1330 battery.

Written By: Kai Kapossy



INTRODUCTION

Is your Dell XPS M1330 not turning on or not holding a charge properly? If so, here is a 2 step guide that will allow you to disassemble and replace the existing battery.



PARTS:

- [Dell XPS M1330 Battery](#) (1)
-

Step 1 — Battery



- Flip the laptop on its back, so that the underside is facing up.

Step 2



- Push and hold the slide button to the left and unlock the mechanism.

Step 3



- Lift the computer up and slowly pull the battery straight out from the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-09 10:05:41 AM.