




# the battery/RAM/HDD door Replacement

Use this guide to access the combined battery, RAM and hard drive compartment in a Fujitsu Lifebook UH572.

Written By: Deib



## INTRODUCTION


Use this guide to access the combined battery, RAM and hard drive compartment in a Fujitsu Lifebook UH572.

---

### TOOLS:

- [T6 Torx Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery/RAM/HDD Door



- Remove the 6 black screws
- To lift the cap use the opening tool.
  - There is a pit.

To reassemble your device, follow these instructions in reverse order. You have to press gently the cap in the reverse direction of the arrows, so the screws fit.

This document was last generated on 2017-06-23 12:14:29 PM.