



Top Cover Replacement

Removing the top cover will allow you to access the rest of the mouse and is required for all other steps. This guide will also allow you to replace the cover.

Written By: Maximilian Betkowski



INTRODUCTION

The first step for all the repair guides for this mouse.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Top cover



- Hold the mouse in your hand so that the bottom side is facing upward.
- Locate the #1 screw towards the bottom half of the mouse.
- Take the 4.76 mm Phillips screwdriver and unscrew the #1 screw that was previously located.

Step 2



- Place the mouse so that the bottom is resting against a hard surface .
- Gently lift the top cover of the mouse and remove.

To reassemble your device, follow these instructions in reverse order.

