



Nintendo GameCube Controller Back Panel Replacement

This guide will demonstrate the removal process of the bottom grip panel. This will allow access to all of the controller's internal parts.

Written By: Jeffrey Hufford



INTRODUCTION

In this step we will be removing the bottom panel from the rest of the controller. This is necessary in order to access the inside components of the controller.

WARNING: Use caution when removing the bottom grip panel. Many of the buttons and components are held only loosely by the front panel and can fall out. Be sure to set screws aside carefully.

TOOLS:

- [Tri-point Y0 Screwdriver](#) (1)
-

Step 1 — Back Panel



- Place the controller (buttons down) on a solid surface.
- Remove the six 9.2mm Tri-wing Y0 screws that hold the back panel in place.

Step 2



- Gently lift the back panel up, separating it from the front panel.
- ⓘ Some of the buttons may fall out if they are knocked around.

To reassemble your device, follow these instructions in reverse order.