



# Palm Treo 680 Battery Replacement

Written By: Maiya123



## INTRODUCTION

This guide shows how to take out the battery in order to access various components.

## Step 1 — Battery



- Remove the battery cover by pressing on the small rectangular button located on the back of the phone.

## Step 2



- Remove the battery by pulling it out towards you.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-09 12:51:36 PM (MST).

