



Palm Treo 680 Battery Replacement

Written By: Maiya123



INTRODUCTION

This guide shows how to take out the battery in order to access various components.

Step 1 — Battery



- Remove the battery cover by pressing on the small rectangular button location the back of the phone.

Step 2



- Remove the battery by pulling it out toward you.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-13 07:14:35 PM.