



Palm Treo 680 Battery Replacement

How to replace a Palm Treo 680 battery.

Written By: Maiya123



INTRODUCTION

This guide shows how to take out the Palm Treo 680 battery in order to access various components.

Step 1 — Battery



- Remove the battery cover by pressing on the small rectangular button located on the back of the phone.

Step 2



- Remove the battery by pulling it out towards you.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-03-09 12:24:18 PM (MST).

