



OnePlus 6T Back Cover Replacement

If your OnePlus 6T back cover is damaged or...

Written By: Kira D'Agostino



INTRODUCTION

If your OnePlus 6T back cover is damaged or scratched, or you need to access the internal components of your phone, follow this simple guide to remove the back cover.

Before you begin, make sure that your phone is powered off and unplugged from the charger.



TOOLS:


[iOpener](#) (1)
[Plastic Cards](#) (1)
[Tweezers](#) (1)
[Jimmy](#) (1)
[Hairdryer or Heat tool](#) (1)



PARTS:

[OnePlus 6T Back Cover](#) (1)
[OnePlus 6T SIM Card Tray](#) (1)

Step 1 — Back Cover




- Make sure the phone is powered off and placed with the back cover facing towards you on a stable surface.

Step 2




- Pop open the SIM card tray by inserting a SIM card removal tool into a small hole on the upper-left side of the phone.
- Carefully remove the SIM card from its tray.

Step 3



- Loosen the binding glue within the phone using a hairdryer or an [iOpener](#).
- ① If you choose to use a hairdryer, hold the dryer at least eight inches from the phone and apply heat for two minutes in a circular motion around the edges of the phone.

Step 4



- Insert a Jimmy under one of the heated corners of the phone to lift it slightly.
- Insert a [plastic card](#) underneath the slightly lifted lip on the back cover and gently glide the card under the lifted phone casing.
- ⓘ There will be a small amount of tension, but this is normal as the card is removing the adhesive within the phone.
- Remove the back cover from the phone.
- ★ Use high concentration (>90%) isopropyl alcohol and a lint-free cloth to remove all adhesive residue from the back cover and the frame.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers community](#) for help.