



Adjust the Action (String Height) on Ibanez SR405QM

In this guide you will learn how to change the height of your strings on your Ibanez SR405QM.

Written By: Chris Pittner



INTRODUCTION

If you need to change the hight of your strings on your Ibanez SR405QM, follow this guide. The height of your strings greatly effects playing. If the strings are too high, it may be difficult to finger the notes with your left hand, and certain techniques like finger style (tapping) maybe be overly difficult. If the strings are too low, they may hit the fret board producing distasteful sounds.

TOOLS:


- [2mm Allen Key](#) (1)
-

Step 1 — Adjust the Action (String Height) on Ibanez SR405QM



- Take note of the distance from both the fret board and pick ups.
- Test the strings and take note of which ones are difficult to play or are producing an unpleasant metallic sound.

Step 2



- Using the 2mm Allen Key, turn the string's corresponding screw clockwise to raise the string and counter clockwise to lower the string.
- The screw is located on the bridge of the guitar next to its corresponding string.
- While modifying a strings height try plucking the string and listening to the sound produced.