



DJI Mavic 2 Pro Battery Replacement

This guide will show you how to remove and replace the DJI Mavic 2 Pro battery.

Written By: Thomas Forcier



INTRODUCTION

This guide may be useful if your DJI Mavic 2 Pro battery is dead, and therefore no longer functioning. This guide will walk you through how to remove and replace the old battery. Before beginning the guide, please verify you have powered the device off.



PARTS:

- [DJI Spark Intelligent Flight Battery](#) (1)

Step 1 — Battery



- Press the buttons on the sides of the drone and pull the battery upwards from the drone to remove it.
- Set aside and charge dead battery.

Step 2



- Press the buttons on the sides of the drone and push the battery downwards into the drone.
- Ensure the battery is secured in place.

If all directions are followed, you have successfully replaced your DJI Mavic 2 Pro battery.