



Replacing Nintendo DS Battery

Guide to removing and replacing the Nintendo DS battery

Written By: dnguye26



INTRODUCTION

This guide will walk you through removing and replacing the Nintendo DS battery.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)

PARTS:

- [Nintendo ds battery](#) (1)

Step 1 — Battery



- Remove the cartridge from the console.
- Use a Phillips #00 Screwdriver to remove the screw securing the battery door to the rear case, turning the screw counter-clockwise.
- Remove the battery door.

Step 2



- Use a plastic opening tool or spudger to pry out the battery from the bottom. If a plastic open tool or spudger isn't available, your fingernails may work.

Step 3



- Remove the battery from the Nintendo DS.

Make sure to press the power button on the Nintendo DS when finished to confirm the battery is working.

This document was last generated on 2019-07-10 11:56:38 PM.