



Toshiba Satellite L305-S5875 Battery Replacement

This guide will show how to remove and replace the battery of your laptop.

Written By: Juan



INTRODUCTION


Replace the battery to provide power to the laptop.

Step 1 — Battery



- Close the laptop lid and flip the laptop over.
- Switch the lock button on the left to the unlock position. (The unlock position is to the left side.)

Step 2



- Push the release button to the right.
- Hold the release button to the right and lift the battery out of its housing.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-16 06:08:02 PM.