




Sony Bloggie 3D Player Front Cover Replacement

Removing the front cover of the Sony Bloggie 3D.

Written By: Robert Tam



INTRODUCTION

This will help you to remove the front cover so you can get to the other parts of the Bloggie 3D Camera.

TOOLS:


- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Front Cover



- Remove the two 2.5mm Phillips #00 screws using the Phillips #00 screwdriver.

Step 2



- Use a plastic opening tool to pry the cover open.
- After the the cover is partly open as shown, remove the cover with your hands.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-08 03:55:08 PM.