




# MSI GP62MVR 6RF Leopard Pro Bottom Cover Replacement

How to remove the bottom cover of the MSI GP62MVR 6RF Leopard Pro.

Written By: Jordan Buck



---

## INTRODUCTION


Use this guide to remove the bottom cover of the MSI GP62VR 6RF Leopard Pro.

---

### TOOLS:

- [Jimmy](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Bottom Cover



- Place the laptop upside down.
- Remove the sixteen 5.5 mm screws with a Phillips #0 screwdriver.

## Step 2



- Use the Jimmy tool to evenly pry loose the bottom cover.
- Ensure that all sides are detached from the plastic hinging before attempting to remove the bottom cover.

## Step 3



- Remove the back cover.
- ⚠ Touching circuitry could damage components or result in personal shock; it is recommended that you now wear latex gloves to prevent both issues.

To reassemble your device, follow these instructions in reverse order.