



Dell Latitude D630 Battery Replacement

Replace the battery in your Dell Latitude D630.

Written By: Justin Ng



INTRODUCTION


Use this guide to replace the battery in your Dell Latitude D630 or to remove it before performing other repairs.

Step 1 — Battery



- Shutdown the computer, detach it from any power source, and make sure the laptop is closed with its latch securely shut.
- Turn the laptop over so its bottom is facing you.
- ⓘ The laptop pictured comes with a palm rest attached to the battery case. This part may not be present on your laptop. Regardless, the steps are exactly the same.

Step 2



- Using two index fingers, slide the battery latches outward.
- While still holding the latches out, use your thumbs to slide the battery out towards you.
- Once the battery is dislodged, you can let go of the latches and remove the battery.

To install your new battery, follow the steps in reverse order and slide your new battery in.