



# Samsung BD-JM57C Top Cover Replacement

Use this guide to remove the top cover of your Samsung BD-JM57C blu-ray player.

Written By: Justin Ogihara



---

## INTRODUCTION

This guide will help you remove the top cover of the blu-ray player.

Prerequisite only.

---

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Top Cover



- Use the Phillips #00 Screwdriver to remove the single 9.6mm screw holding the top cover in place.
- Remove the cover by sliding it up and then out.

To reassemble your device, follow these instructions in reverse order.