



Western Digital Essentials HD Case Replacement

Only prerequisite guide for disassembling Western Digital Essentials HD


Written By: Gaetan



 **TOOLS:**

- [iFixit Opening Tools](#) (1)
-

Step 1 — Case



- Use a large plastic opening tool along the rear panel:
 - There are 4 clips to release.

Step 2



- Slide the cover along the plastic frame.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-09 09:06:24 AM.