




Removing the Dell Inspiron 1150 Hard Drive

This guide will show you how to remove the hard drive from your dell 1150 laptop


Written By: Richdave



 **TOOLS:**

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Hard Drive



- Place laptop upside down on a clean flat surface.
- Remove 2ea M2.5 x 5 mm screws.
- Pull the HDD from main body of the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-13 06:53:20 PM.