



BlackBerry 8820 Battery Replacement

Install a new battery in your BlackBerry 8820.

Written By: Benjamin Morris



INTRODUCTION

Fix a dead battery by replacing it with a fresh one.



PARTS:

- [Spudger](#) (1)
-

Step 1 — Battery



- Hold down the silver square in the middle of the rear cover.
- Slide the rear cover down to remove it.
- Lift the battery up and out of the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 05:26:55 PM.