



# Removing the HP Elitebook 6930p Bluetooth module

This guide will show you how to locate and remove the Bluetooth module

Written By: Richdave



---

## INTRODUCTION

This guide will show you how to locate and remove the Bluetooth module

---

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Battery Removal



- Flip laptop over and locate the battery release button
- Push release button to the left to release battery and gently pull battery from the laptop

## Step 2 — Bluetooth module



- Locate the Bluetooth module cover on the bottom of the laptop
- Loosen the M2.0×5.0 **captive** screw and remove the cover by by lifting it straight up
- ⚠ The Bluetooth module is connected to the laptop via a small cable with very fine wires - take care not to damage the cable when you pull the module out of the case.
- Gently lift the Bluetooth module up and over the retaining clip. A plastic spudger may be useful.
- Disconnect the connector being careful not to damage the fine wires on the cable.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-23 08:06:53 PM.