




Disassembling Creative Ziio 7" Back Panel

This guide will show how to remove the back panel of the Creative Ziio 7"

Written By: Benedict Samoy




INTRODUCTION

This guide is simple and will be a prerequisite for every installation guide for the Creative Ziiio 7" device.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Back Panel



- Remove the back panel by using the plastic opening tool to carefully pry around the panel's edges.
⚠ The volume control button and the top power button may fall out during this step.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-09 11:52:35 AM.