



# Microsoft Zune HD Upper Rear Panel Replacement

Written By: Walter Galan



---

## INTRODUCTION

Replace the upper rear panel and keep your Zune HD nice and shiny.

---

### TOOLS:

- [Tri-wing Screwdriver](#) (1)
-

## Step 1 — Upper Rear Panel



- Remove the four Tri-Wing screws securing the upper rear panel to the inner chassis.

## Step 2



- Slightly rotate the top edge of the upper rear panel away from the Zune.
- Lift the upper rear panel straight up off the black plastic lower rear panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-18 09:07:29 AM.