



HyperX Cloud Alpha Headband Replacement

The adjustment slider helps the headphones...

Written By: Shelsea Rodriguez



INTRODUCTION

The adjustment slider helps the headphones change their size to either tight or loose around the head depending on your preference. If your headband is not adjusting properly or is uncomfortable, try referring back to the [HyperX Cloud Alpha Troubleshooting page](#). If our troubleshooting page is of no use, use our replacement guide to replace the slider.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)

Step 1 — Headband






- Remove the two Phillips #1 screws from the clips located on the headband.
- Repeat on the other clip. (If you did the right side first, then do the left and vice-versa.)

Step 2



- Remove the black plastic clips, freeing the metal sliding band inside.

Step 3



- Remove the worn band.

To reassemble your device, follow these instructions in reverse order.