

How to clean the Nintendo 64 cartridge slot

Written By: tonymag28



INTRODUCTION

Cleaning the cartridge slot will fix most of the problems with the Nintendo 64.



TOOLS:

- Q-Tips (1)
- Compressed Air (1)

Step 1 — How to clean the Nintendo 64 cartridge slot



 Open the slot with your finger. Blow along the length of the cartridge slot with the air duster.

Step 2



Moist a q-tip with rubbing alcohol.
Rub it along the length of the cartridge slot.

If cleaning the cartridge slot worked, you should be able to insert a game and play normally. If the game still does not boot normally, check to make sure the pins are not damaged, and that the cartridge does not need cleaning.

This document was last generated on 2019-04-06 03:09:16 PM.