



Xbox Hard Drive Management

Deleting items from the Xbox hard drive using the Dashboard.

Written By: Eddie Meehan



Step 1 — Xbox Hard Drive Management



- Boot up your Xbox without a disc in the drive and you will get the dashboard. Head to "Memory", as the Xbox doesn't have a single format HD option.

Step 2



- Here you can see the Xbox hard drive options. Select the save you want to delete, and hit A.

Step 3



- Press A to delete the save. Then go back and delete all the other saves you want to delete. Now your Xbox HD is completely clear of savegames.
- If you're selling your Xbox, go to Settings and turn off auto-login and go to Xbox LIVE and remove your account options.

Make sure you haven't left any music on your Xbox HD if you're selling your Xbox.

This document was last generated on 2019-07-18 10:45:45 PM.