



Palm IIIx Battery Replacement

How to replace a Palm IIIx battery.

Written By: David Haskell



INTRODUCTION

Explains how to replace old or damaged batteries with new ones.

Step 1 — Battery



- Place the Palm IIIx face down on a flat surface.

Step 2



- Push down and lift up the battery cover to remove it.

Step 3



- Remove the old batteries one at a time.

To reassemble your device, follow these instructions in reverse order.