



Palm IIIx Battery Replacement

Written By: David Haskell



INTRODUCTION

Explains how to replace old or damaged batteries with new ones.

Step 1 — Battery



- Place the Palm IIIx face down on a flat surface.

Step 2



- Push down, lift up on, and remove battery cover.

Step 3



- Remove the old batteries one at a time.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-10 08:15:53 PM.