



# Gateway KAV60 LT2016U RAM Replacement

Gateway KAV60 LT2016U RAM replacement.

Written By: Lydia Benjock



---

## INTRODUCTION

The RAM can be replaced if you have a Phillips #0 screwdriver.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery



- Unlock the tab located in the top left corner of the netbook.
  - The red tab indicated that the battery has been properly unlocked.
  - Remove the battery.
- i** When working with electronics, it is always wise to remove the power source before taking the device apart.

## Step 2 — RAM




- The RAM is located under this cover.

### Step 3



- Using a Phillips #0 screwdriver, remove one (1) 5mm screw holding the cover in place.
- Use a plastic opening tool to remove the cover.

### Step 4



- Unlock the RAM by pinching the metal clamps that keep the RAM in place.
- Remove the RAM while the metal clamps are disengaged.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-18 05:55:48 PM.