



How to clean Game Boy Advance buttons

Written By: Adam



INTRODUCTION

Use this repair guide to clean sticky buttons.

TOOLS:

- Cloth (1)
 - tooth brush (1)
-

Step 1 — How to clean Game Boy Advance buttons



- Use a slightly damp toothbrush to scrape in between the desired sticky buttons.

⚠ Make sure toothbrush is not to the point of dripping water when scraping.

Step 2



- Dry with a cloth after the sticky residue is removed.