




# Game Boy Advance Back Panel Replacement

Written By: Aldo Corona



---

## INTRODUCTION

How to remove the back panel from a Game Boy Advance.

---

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [Tri-wing Screwdriver](#) (1)
-

## Step 1 — Battery



- Take the battery cover off by releasing the locking tab and hinging the cover away.

## Step 2 — Back Panel




- Remove the six back panel screws using a Tri-wing Screwdriver.

### Step 3



- Remove bottom back panel screw with a Phillips #1 screw driver.

### Step 4



- Remove the back panel by pulling away with one hand and the front secured in the other hand.
- ⚠ Removal of the back panel may cause shoulder buttons and side panels to come loose and fall off.

To reassemble your device, follow these instructions in reverse order.